

Mesh Floor Saver



Key Features:

- Protects PVC floor
- Extends floor area to under awning
- Mesh allows water, sand and dirt to pass through
- Fits exact dimensions of your Oztent



Description:

The Oztent mesh floor saver extends all the way underneath the base of the tent and out to the front of the awning. While enhancing your living area it also serves to further protect the floor of your Oztent from sharp and abrasive objects and keeps it from getting dirty. This is a handy option to help prolong the life of your tent and great when used in conjunction with Peaked Sides and Front Panel.

Mesh Floor Saver



Specifications:

Material	
Mesh Floor	Double woven mesh
Dimensions	
Size	RV-1 Mesh Floor Saver 370cm (l) x 215cm (w) 4'11" (l) x 7' (w)
	RV-2 Mesh Floor Saver 400cm (l) x 200cm (w) 6'7" (l) x 6'7" (w)
	RV-3 Mesh Floor Saver 400cm (l) x 240cm (w) 7'10" (l) x 7'10" (w)
	RV-4 Mesh Floor Saver 440cm (l) x 240cm (w) 7'10" (l) x 7'10" (w)
	RV-5 Mesh Floor Saver 460cm (l) x 260cm (w) 8'6" (l) x 8'6" (w)
Weight	2.19kg - 2.92kg 5 - 7 lbs
Warranty	
Warranty Period	2 years
Warranty Type	Manufacturers
Package Contents	Quantity
Pegs/Stakes	6
Swing Tag	1
Carry Bag	1

All images shown remain the property of the publisher. All images used in this datasheet are for illustration purposes only and actual items may vary in appearance. Precautions have been taken to assure accuracy of the information on this sheet. Typographic or pictorial errors that are brought to our attention will be corrected in subsequent updates. Product dimensions shown here are nominal and are provided for the convenience of our customers. The Oztent Group reserves the right to make product changes from time to time, without prior notification, which may change the dimensions shown. The designs and dimensions of the products listed on this sheet are correct at the date of last publication and are subject to change without notice.