




INSTALL TIME: 30 mins



Thank you for purchasing a Front Runner Storage System.

This Storage System is made up of the following components:

1. A Drawer System - SDDR011
2. A Vehicle Specific Mounting Plate - SSST02

Before you start, take a moment to familiarize yourself with these Fitting Instructions and all the components received. Depending on the vehicle not all components received will be used. Refer to Page 2 for a list of all the components and quantities if required.


IMPORTANT WARNING!

IT IS CRITICAL THAT ALL FRONT RUNNER PRODUCTS BE PROPERLY AND SECURELY ASSEMBLED AND ATTACHED TO YOUR VEHICLE. IMPROPER ATTACHMENT COULD RESULT IN AN AUTOMOBILE ACCIDENT, AND COULD CAUSE SERIOUS BODILY INJURY OR DEATH TO YOU OR TO OTHERS. YOU ARE RESPONSIBLE FOR ASSEMBLING AND SECURING ALL FRONT RUNNER PRODUCTS TO YOUR VEHICLE, CHECKING THE ATTACHMENTS PRIOR TO USE, AND PERIODICALLY INSPECTING THE PRODUCTS FOR ADJUSTMENT, WEAR, AND DAMAGE. THEREFORE, YOU MUST READ AND UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS SUPPLIED WITH YOUR FRONT RUNNER PRODUCT PRIOR TO INSTALLATION OR USE. IF YOU DO NOT UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS, OR IF YOU HAVE NO MECHANICAL EXPERIENCE AND ARE NOT THOROUGHLY FAMILIAR WITH THE INSTALLATION PROCEDURES, YOU SHOULD HAVE THE PRODUCT INSTALLED BY A PROFESSIONAL INSTALLER OR OTHER QUALIFIED PERSONNEL.

1 GET ORGANIZED...


Here is what you are looking at for SSSDR011:

Item #	Quantity	Description
1	1	DRAWER SYSTEM
2	4	TURN BUCKLE
3	2	M6 WING NUT
4	4	D-RING
5	4	M6 x 20 HEX BOLT
6	4	M6 SPRING WASHER
7	4	M6 x 19 x 1 FLAT WASHER
8	4	M6 EYE NUT
9	4	M6 STUD PLATE
10	4	NYLON WASHER





You will need:

- 10 mm Flat & Socket Wrench
- Long Socket Extension
- 4 mm Hex Key
- a Friend




Here is what you are looking at for SSST002:

Item #	Quantity	Description
11	2	37mm C_HOOK
12	4	M6 NUT CAP
13	2	M6 x 25 HEX BOLT
14	2	M6 SPRING WASHER
15	4	M6 x 19 FLAT WASHER
16	2	M6 NYLOC NUT
17	1	MOUNTING PLATE




2 PREPARE FOR INSTALLATION

- (A) Loosen the round end of the two Turn Buckles (Item 2) supplied with SSDR011 and assemble a M6 Wing Nut (Item 3) as shown. Reassemble the Turn Buckle.



- (B) Remove the storage cover from the vehicle. Lift the plastic storage liner and remove the jack and toolkit from the vehicle. Replace the plastic liner.



Storage Cover



Plastic Liner



Jack & Toolkit

- (C) Loosen and remove the two tie down rings either side of the vehicle as indicated. The threaded mounting points in the vehicle's body will be used to secure the Mounting Plate (Item 12) to the vehicle in Step 3A.




2 PREPARE FOR INSTALLATION CONT...


- (D) If the two original tie down rings (as indicated by the arrows) have been removed from the vehicle, they need to be refitted. If the original tie down rings have been lost, use two D-rings, two M6 x 20 Hex Bolts, two M6 x 19 Flat Washers and two M6 Spring Washers (Items 4, 5, 6, 7) supplied with SSDR011 in their place.





Sample of D-ring, M6 x 20 Hex Bolt, M6 x 19 Flat Washer and M6 Spring Washer if required.



- (E) Working at the rear of the Drawer System, remove the top M6 Hex Bolt on both the left and right hand side of the Drawer. Secure a D-ring (Item 4) to each corner using a M6 x 20 Hex Bolt, M6 Spring Washer and M6 Spring Washer (Items 5, 6, 7) as shown.




- (F) Remove the Cage Nuts from the left side, right side and rear of the Drawer as indicated by the arrows. When removing the rear cage nuts, lie the Drawer System on its side and open the Drawer to gain access.




3 INSTALL DRAWER SYSTEM

- (A) Place the Mounting plate (Item 17) into position, lining up the two mounting holes in the Plate with the threaded mounting points in the vehicle's body from Step 2C. Secure the Plate to the vehicle using two M6 x 25 Hex Bolts, two M6 Spring Washers and two M6 x 19 Flat Washers (Items 13, 14 ,15). Place a M6 Nut Cap (Item 12) over each Hex Bolt.




- (B) Place the Drawer System into the vehicle. The front square cutouts in the base of the Drawer sit over the studs in the Mounting Plate as shown. Secure the Drawer to the vehicle using two M6 Nyloc Nuts and two M6 x 19 Flat Washers (Items 15, 16). Place a M6 Nut Cap (Item 12) over each of the Nyloc Nuts.



3

INSTALL DRAWER SYSTEM

- (C) Using the two Turn Buckles from Step 2A and the two 37 mm C-hooks (Item 11), secure the rear of the Drawer System to the vehicle as shown. Once the rear of the Drawer System is secure, tighten the Wing Nuts.



- (D) Congratulations, you have completed your installation. Take a step back and admire your work. Good Job!

